

REPAIR KIT INSTRUCTIONS

PATCH MIX

1. In one of the empty clear containers, fill up about $\frac{1}{4}$ of the cup with the colored grout mix.
2. Pour in the Admixture and mix. Start slow and add more Admix as needed until you get a creamy consistency.
3. Using one of the wooden depressor's (or a square razor blade/slim putty knife), apply the mix to your repair area and shape the mix application as best as possible so there isn't a large amount of excess.
4. If it's a large chip repair, you may need to fill partially, let dry for a bit, and then add another layer on top.
5. Let the repair dry overnight if possible. On a small chip repair, the grout mix would likely be dry in a couple hours.
6. Once the fill is dry (the color will lighten and feel solid to touch) you can sand with 150-220 grit sandpaper to shape and smooth out the repair.

SEALER

1. For polished finishes, start with the Epoxy. If acid wash/boardform finish, skip to sealer. The epoxy is mixed 2 parts RESIN to 1 part HARDENER in one of the empty clear containers. Mix well.
2. Use a microfiber towel to dab some epoxy onto the fill spot.
3. Once concrete color matches the surrounding concrete, wipe off excess epoxy. This could be as soon as immediately to several minutes.
4. Let the epoxy dry, preferably overnight. On small repairs, the epoxy will likely dry in a couple of hours.
5. Once dry (no tackiness to touch), you can apply the final sealer, which is labeled as the sealer container.
6. Similarly, with a microfiber towel, lightly apply some sealer to the fill spot. 2 coats would be recommended, a couple hours in between coats.